


### NOAA Fisheries TED Technology Transfer Program P.O. Drawer 1207, Pascagoula, MS USA www mslabs noaa gov/teds.html PH: 228-762-4591

Step 1


Step 3



# Guide for Checking 71-inch TED Opening

Step 2

### Step 1



Measure the distance from the TED frame forward along the side of the escape hole cut to the leading edge of the escape hole cut **A to B**.

This measurement must be greater than or equal to **26-inches** when stretched.

Measure the distance

the flap is attached

This measurement

must be taken from

frame and must not

the center of the

exceed 6-inches


when the TED is

edge of the TED frame **E to F**.

beyond the posterior

# 24" Max.

## Step 4



### Step 4


Measure the leading edge of the escape hole cut **G to H.** 

This measurement must be greater than or equal to **71-inches** when stretched.


### Note:

This measurement must also be obtained with flap attached.

### Step 3



### Step 5



### Step 5

hanging.

Measure the escape opening (inside the flap) **I to J**.

This measurement must be greater than or equal to **71-inches** when stretched.

Take this measurement in a horizontal straight line at the aft edge of the exit hole.

# ACCELERATOR FUNNELS

If an optional accelerator funnel is used, the funnel must have a minimum straight-line stretched measurement as follows:

All offshore waters and the inshore waters of Georgia or South Carolina = 71"

All inshore waters except GA & SC = 44"

### Step 2

Measure the distance from the posterior edge of the TED frame to the trailing edge of the flap **C to D**.

This measurement must be taken from the center of the frame and must not exceed **24-inches** as the TED is hanging (<u>not stretched</u>).